



INSTALLATION MANUAL AND OPERATING INSTRUCTIONS

MD200-2XX SERIES COURSE DEVIATION INDICATOR

MFG. P/N: MD200-202/-202(5V)

MFG. P/N: MD200-203/-203(5V)

MFG. P/N: MD200-206/-206(5V)

MFG. P/N: MD200-207/-207(5V)



Mid-Continent Instruments and Avionics
9400 E. 34th Street N.
Wichita, KS 67226 USA
Phone: 316-630-0101
Fax: 316-630-0723

Manual Number 8017702
REV. D, 11/21/2013

FOREWORD

This manual provides information intended for use by persons who, in accordance with current regulatory requirements, are qualified to install this equipment. If further information is required, please contact:

Mid-Continent Instruments and Avionics
Attn: Customer Service Dept.
9400 E. 34th St. N.
Wichita, KS 67226 USA
Phone 316-630-0101
Fax 316-630-0723
ks.customerservice@mcico.com
www.mcico.com

We welcome your comments concerning this manual. Although every effort has been made to keep it free of errors, some may occur. When reporting a specific problem, please describe it briefly and include the manual part number, the paragraph/figure/table number, and the page number. Send your comments to:

Mid-Continent Instruments and Avionics
Attn: Customer Service Dept.
9400 E. 34th St. N.
Wichita, KS 67226 USA
Phone 316-630-0101
Fax 316-630-0723
ks.customerservice@mcico.com

©Copyright 2003
Mid-Continent Instrument Co., Inc.

Revisions

Rev.	Date	Approved	Description of Change
A	4/11/02		Added MD200-202(5V)/-203(5V)/-206(5V)/-207(5V) indicators. These units have 5 volt bezel lighting.
B	6/20/02		5V lighting was on pin 23.
C	9/12/03		Correction made to table of contents.
D	11/21/13	MKN/BMC	Updated to standardized formatting, added Foreword, added ETSO info, corrected course datum synchronization wiring diagrams, corrected environmental qualification form, added dimming instructions.

This page intentionally blank

TABLE OF CONTENTS

SECTION 1: GENERAL DESCRIPTION.....	7
1.1 INTRODUCTION	7
1.2 SPECIFICATIONS, TECHNICAL.....	7
1.2.1 PHYSICAL CHARACTERISTICS	7
1.2.2 ENVIRONMENTAL CHARACTERISTICS	7
1.2.3 SPECIFICATIONS, ELECTRICAL	8
1.2.4 FRONT PANEL CONTROLS	8
1.2.5 INTERFACE.....	8
1.2.6 EQUIPMENT LIMITATIONS.....	9
1.2.7 MAJOR COMPONENTS.....	9
SECTION 2: INSTALLATION CONSIDERATIONS	11
2.1 COOLING	11
2.2 EQUIPMENT LOCATION	11
2.3 ROUTING OF CABLES	11
SECTION 3: INSTALLATION PROCEDURES.....	13
3.1 GENERAL INFORMATION.....	13
3.2 UNPACKING AND INSPECTING EQUIPMENT.....	13
3.3 MOUNTING THE MD200-() INDICATOR.....	13
3.4 INSTALLATION LIMITATIONS.....	13
SECTION 4: POST INSTALLATION CHECK.....	17
4.1 PRE-INSTALLATION TESTS	17
4.2 ANNUNCIATOR DIMMING ADJUSTMENT	17
4.3 OPERATING INSTRUCTIONS.....	17
4.3.1 VOR OPERATION.....	17
4.3.2 LOCALIZER OPERATION	18
4.3.3 GLIDESLOPE OPERATION.....	18
ENVIRONMENTAL QUALIFICATION FORM.....	19
FIGURE NO. LIST OF ILLUSTRATIONS:	
FIGURE 3-1: REAR VIEW OF MATING CONNECTORS.....	14
FIGURE 3-2: CUTOUT DIMENSIONS FOR PANEL MOUNTING	14
FIGURE 3-3: OUTLINE DRAWING.....	15
FIGURE 3-4: WIRING DIAGRAM, MD200-202/-203	16
FIGURE 3-5: WIRING DIAGRAM, MD200-206/-207	16

This page intentionally blank

SECTION 1: GENERAL DESCRIPTION

1.1 INTRODUCTION

The Mid-Continent Instruments and Avionics MD200-202/-203/-206/-207 Nav Indicator is designed to operate with VHF and GPS navigational equipment to provide OMNI (VOR), GPS, Localizer (LOC), and Glideslope (GS) information.

The MD200-202/-203 is designed to accept DC Left/Right, To/From, and Nav warn flag signals from a remote mounted VOR converter. Additionally, the MD200-206/-207 will accept DC signals from a glideslope receiver which will drive the Up/Down needle along with a GS warn meter. Both units incorporate NAV, GPS, and VLOC annunciation with photocell dimming.

When GPS is selected for display, the MD200-() receives inputs from compatible GPS/Navigation receivers or Flight Management Systems to provide a visual presentation to the pilot. All information presented on the navigation indicator is generated from this external receiver.

Course datum information is offered on the MD200-203/-207 versions. The course resolver is ORZ zeroed to industry standard 300°.

5 volt bezel lighting is offered with the MD200-202(5V)/-203(5V)/-206(5V)/-207(5V) indicators.

1.2 SPECIFICATIONS, TECHNICAL

1.2.1 PHYSICAL CHARACTERISTICS

Size:	3 1/8 Inch Round
Mounting:	Panel
Width:	3.25 Inches
Height:	3.25 Inches
Depth:	4.75 Inches max
Weight:	MD200-202/-206 1.4 lbs. MD200-203/-207 1.5 lbs.

1.2.2 ENVIRONMENTAL CHARACTERISTICS

TSO Compliance:	TSO C34e, C36e, C40c
ETSO Compliance:	ETSO C34e, C36e, 2C40c
Applicable Documents:	RTCA DO-160B, DO-192, DO-195, DO-196
Operating Temperature Range:	-55°C to +70°C
Humidity:	95% Non-Condensing
Altitude Range:	0 to 55,000 ft.
Vibration:	Cat. M and N
Operational Shock:	Rigid Mounting, 6 G Operational 15 G Crash Safety

1.2.3 SPECIFICATIONS, ELECTRICAL

1.2.3.1 GENERAL

DESIGN: All Solid State
OPERATING CURRENT: All units 0.30 Amps

1.2.3.2 VOR/LOC/GPS

OBS RESOLVER: Electrical zero: $300^{\circ} \pm 1^{\circ}$ ORZ.
DEVIATION: Input impedance: 1K ohms $\pm 10\%$.
Deflection sensitivity: + and -150 mV $\pm 10\%$ for full scale deflection.
VALID FLAG: Input impedance: 1K ohms $\pm 10\%$.
Flag sensitivity: 125 mV +10% for flag to leave stop. 260 mV $\pm 10\%$ flag fully concealed.
TO/FROM FLAG: 200 ohms $\pm 10\%$. + and -40 mV $\pm 15\%$ flag fully in view.
COURSE DATUM: Standard ARINC X, Y, Z, 11.8 VRMS, (MD200-203/-207 only) 0.030 Amp. 400 Hz.

1.2.3.3 GLIDESLOPE (MD200-206/-207 only)

DEVIATION: Input impedance: 1K ohms $\pm 10\%$.
Deflection sensitivity: + and -150 mV $\pm 10\%$ for full scale deflection.
VALID FLAG: Input impedance: 1K ohms $\pm 10\%$.
Flag sensitivity: 125 mV +10% for flag to leave stop. 260 mV $\pm 10\%$ flag fully concealed.

1.2.4 FRONT PANEL CONTROLS

OBS: Used to select appropriate inbound or
outbound bearing to a VOR station or waypoint.

1.2.5 INTERFACE

NAV/LOC/GPS: Receives vertical, lateral deviation, warn flags, To/From, and OBS resolver information from the GPS/NAV receiver.
GLIDESLOPE: Receives GS up-down and warn flag input from glideslope receiver.

1.2.6 EQUIPMENT LIMITATIONS

REQUIREMENTS FOR TSO'D VOR/ILS SYSTEM:

1. The navigation receiver shall be certified to the standards of TSO C40a/b/c or TSO C36c/d/e.
2. VOR phase error shall not exceed 1.5°.
3. Variation in VOR composite output not to exceed ± 3 dB from .500 VRMS as the RF input level of a standard VOR test signal to the receiver is varied from 10 μ V to 10,000 μ V.
4. Variation in the LOC composite output not to exceed ± 2 dB from .333 VRMS as the RF input level of a standard localizer test signal to the receiver is varied from 50 μ V to 10,000 μ V.
5. A control line (ILS Energize) must be provided as a low impedance to ground when an ILS frequency is selected.

REQUIREMENTS FOR TSO'D GLIDESLOPE SYSTEM:

1. The glideslope receiver/converter shall be certified to the standards of TSO C34c/d/e.
2. The centering error as presented to the pilot shall not exceed 13% of standard deflection with a 95% probability under all combinations of the service conditions listed in RTCA document DO-192.
3. Deviation current with a 700 μ V standard glideslope deviation signal applied to the receiver input shall be 78 μ A $\pm 10\%$ into a 1000 ohm load. Deviation current shall not change more than 15% as the RF level of a standard glideslope deviation signal is varied from 100 μ A to 10,000 μ A. Deviation current shall be proportional within 5% to the difference in depth of modulation of the 90 Hz and 150 Hz tones.
4. Warning signal output shall be a DC current less than 125 μ A into a 1000 ohm load for a warning flag to be fully visible. Warning signal for a fully concealed warning flag shall be a DC current of 260 μ A minimum into a 1000 ohm load.

1.2.7 MAJOR COMPONENTS

The system is comprised of one major component, the MD200-() Course Deviation Indicator.

This page intentionally blank

SECTION 2: INSTALLATION CONSIDERATIONS

2.1 COOLING

No direct cooling is required. As with any electronic equipment, overall reliability may be increased if the MD200-() is not located near any high heat source or crowded next to other equipment.

2.2 EQUIPMENT LOCATION

The MD200-() course deviation indicator must be mounted as close to the pilot's field of view as possible. The unit depth, with connector attached, must also be taken into consideration.

2.3 ROUTING OF CABLES

Care must be taken not to bundle the MD200-() logic and low level signal lines with any high energy sources. Examples of these sources include 400 Hz AC, COM, DME, HF, and transponder transmitter coax. Always use shielded wire when shown on the installation print. Avoid sharp bends in cabling and routing near aircraft control cables.

This page intentionally blank

SECTION 3: INSTALLATION PROCEDURES

3.1 GENERAL INFORMATION

This section contains interconnect diagrams, mounting dimensions, and other information pertaining to the installation of the MD200-(). After installation of cabling and before installation of the equipment, ensure that power is applied only to the pins specified in the interconnect diagram.

3.2 UNPACKING AND INSPECTING EQUIPMENT

When unpacking equipment, make a visual inspection for evidence of damage incurred during shipment. The following parts should be included:

1. MD200-() Series Course Deviation Indicator
2. Connector Kit (9 pin) MCI P/N 8017287 (-203/-207 w/course datum only)
3. Connector Kit (25 pin) MCI P/N 7014517
4. Installation Manual MCI P/N 8017702

3.3 MOUNTING THE MD200-() INDICATOR

Plan a location in the aircraft for the MD200-() course deviation indicator to be mounted as close to the pilot's field of view as possible. Avoid mounting close to heater vents or other high heat sources. Allow a clearance of at least 3 inches from back of unit for plug removal.

The indicator is secured in place behind the panel since it is designed for rear mount only. Make a panel cutout as shown in Figure 3.2. Secure the indicator in place with three 6-32 x 1.0" flat head Phillips screws

3.4 INSTALLATION LIMITATIONS

Wire the aircraft harness according to the appropriate figure. Use at least 24 AWG wire for all connections. You MUST use shielded wire where shown by the receiver manufacturer. Avoid sharp bends and routing cables near high energy sources. Care must be taken to tie the harness away from aircraft controls and cables.




FIGURE 3-1: REAR VIEW OF MATING CONNECTORS






FIGURE 3-2: CUTOUT DIMENSIONS FOR PANEL MOUNTING



MD200-202/-203



MD200-206/-207






FIGURE 3-3: OUTLINE DRAWING



* GROUND FOR 14 VOLT LIGHTING
 ** 5 VOLT FOR MD200-202(5V) AND -203(5V)

FIGURE 3-4: WIRING DIAGRAM, MD200-202/-203



* GROUND FOR 14 VOLT LIGHTING
 ** 5 VOLT MD200-206(5V) AND -207(5V)

FIGURE 3-5: WIRING DIAGRAM, MD200-206/-207

SECTION 4: POST INSTALLATION CHECK

4.1 PRE-INSTALLATION TESTS

With the MD200-() indicator disconnected, turn on the avionics master switch and verify that aircraft power on J1 pin 19 is 14 VDC or pin 20 is 28 VDC. Using an ohmmeter, verify pin 21 is aircraft ground.

4.2 ANNUNCIATOR DIMMING ADJUSTMENT

Following installation of the MD200-() CDI, check the brightness of the GPS, NAV, and VLOC annunciations as necessary with the ambient and aircraft panel lighting levels set to simulate minimum-light operations. If required, the dimming adjustment is located on the side of the MD200-() unit, and is labeled "ANNUN DIM ADJ".

4.3 OPERATING INSTRUCTIONS

All controls required to operate the MD200-() course deviation indicator are located on the unit's front panel and on the front panel of the related navigation receiver.

4.3.1 VOR OPERATION

Channel the NAV receiver to the desired VOR frequency and positively identify the station by listening to received audio. Determine the NAV warning flag is out of view.

Flying inbound to a VOR station is accomplished by first rotating the OBS knob to center the deviation indicator, and determining the To/From meter is in the "To" condition. The aircraft is then turned to a magnetic heading, which is the same as the selected course with proper allowance for wind correction. When the aircraft is on course, the vertical pointer will be centered. If the aircraft moves off course, the deviation indicator will move away from the center position and flying in the direction of pointer deflection (left or right) is required to re-intercept the course.

The procedure for flying outbound from a VOR station is the same as flying inbound, except the OBS knob is first rotated to cause a "From" indication to appear with the pointer centered.

To intercept a selected VOR radial (from the station) and fly outbound, turn the OBS control to set the desired radial under the top indicator index. Maneuver the aircraft to fly the selected radial magnetic heading plus 45° intercept angle which will provide a sufficient intercept angle. The intercept angle should be reduced as the deviation needle approaches an on course condition (center) to prevent excessive course bracketing.


4.3.2 LOCALIZER OPERATION

Select the desired localizer frequency and observe that the localizer warning flag is concealed. The To/From flag is not functional for localizer operation. When flying on the front course or outbound on the back course make corrections toward the localizer (vertical) needle deflection. The localizer path narrows as the approach end of the runway becomes closer. When flying inbound on the back course or outbound on the front course, the corrections are made away from the direction of needle deflection. A helpful hint when flying the localizer is to set the localizer heading on the OBS dial under the lubber line for quick reference.

4.3.3 GLIDESLOPE OPERATION

The glideslope (horizontal) needle provides the pilot with vertical steering information during ILS approaches. The glideslope circuitry is energized when the associated localizer frequency is selected on the navigation receiver. Observe that the glideslope warning flag is concealed. The glideslope needle deflects towards the direction the pilot must fly to remain on the glide path.

If the glideslope needle deflects upward the aircraft is below the glide path and the pilot must climb to again intercept the glide path and center the needle. If the needle deflects downward the aircraft is above the glide path and the pilot must descend to again intercept the glide path and center the needle. When the needle is centered the aircraft is on the glide path.



ENVIRONMENTAL QUALIFICATION FORM
RTCA / DO160B

NOMENCLATURE: MD200-() COURSE DEVIATION INDICATOR
MODEL NO.: MD200-()

TSO NO.: C34e, C36e, C40c
ETSO NO.: C34e, C36e, 2C40c
MPS 8014565

MANUFACTURER TEST SPECIFICATIONS

MANUFACTURER: Mid-Continent Instruments and Avionics
9400 E. 34th Street N.
Wichita, KS 67226
Phone (316) 630-0101

Conditions	Section	Description of Conducted Tests
Temperature and Altitude	4.0	Equipment tested to Categories F2 except as noted
Low Temperature	4.5.1	
High Temperature	4.5.2 & 4.5.3	
Altitude		
Decompression	4.6.1	Not Tested
Overpressure	4.6,2 4.6.3	Not tested
Temperature Variation	5.3	Equipment tested to Category B
Humidity	6.0	Equipment tested to Category A
Shock	7.0	Equipment tested per DO-160B
Operational	7.2.1	
Crash Safety	7.3.1	
Vibration	8.0	Equipment tested without shock mounts to Categories M and N (Table 8-1)
Explosion	9.0	Equipment identified as Category X, no test required
Waterproofness	10.0	Equipment identified as Category X, no test required
Fluids Susceptibility	11.0	Equipment identified as Category X, no test required
Sand and Dust	12.0	Equipment identified as Category X, no test required
Fungus	13.0	Equipment identified as Category X, no test required
Salt Spray	14.0	Equipment identified as Category X, no test required
Magnetic Effect	15.0	Equipment tested to Class Z
Power Input	16.0	Equipment tested to Category B
Voltage Spike	17.0	Equipment tested to Category B
Audio Frequency Susceptibility	18.0	Equipment tested to Category B
Induced Signal Susceptibility	19.0	Equipment tested to Category B
Radio Frequency Susceptibility	20.0	Equipment tested to Category B
Radio Frequency Emissions	21.0	Equipment tested to Category B
Lighting Induced Transient Susceptibility	22.0	Equipment identified as Category X, no test required
Lighting Direct Effects	23.0	Equipment identified as Category X, no test required
Icing	24.0	Equipment identified as Category X, no test required